

Hitachi Dynamic Link Manager (for Windows®) 8.7.3-01 Release Notes

Contents

About this document.....	1
Intended audience.....	2
Getting help	2
Accessing product downloads.....	2
About this release	2
Product package contents.....	2
New features and important enhancements	3
System requirements.....	3
Resolved problems	6
Known problems	7
Installation precautions.....	7
Usage precautions.....	8
Documentation	11
Appendix A.....	12
Copyrights and licenses	25

About this document

This document (RN-00HS272-53, July 2020) provides late-breaking information about Dynamic Link Manager (for Windows®) 8.7.3-01. It includes information that was not available at the time the technical documentation for this product was published, as well as a list of known problems and solutions.

Intended audience

This document is intended for customers and Hitachi Vantara partners who license and use Hitachi Dynamic Link Manager (for Windows®).

Getting help

[Hitachi Vantara Support Connect](https://support.hitachivantara.com/en_us/contact-us.html) is the destination for technical support of products and solutions sold by Hitachi Vantara. To contact technical support, log on to Hitachi Vantara Support Connect for contact information:

https://support.hitachivantara.com/en_us/contact-us.html.

[Hitachi Vantara Community](https://community.hitachivantara.com) is a global online community for customers, partners, independent software vendors, employees, and prospects. It is the destination to get answers, discover insights, and make connections. **Join the conversation today!** Go to community.hitachivantara.com, register, and complete your profile.

Accessing product downloads

Product software, drivers, and firmware downloads are available on Hitachi Vantara Support Connect: <https://support.hitachivantara.com/>.

Log in and select Product Downloads to access the most current downloads, including important updates that may have been made after the release of the product.

About this release

This is a minor release.

Product package contents

Medium	CD-ROM	Revision	Release Type	Prerequisite version of Service Pack
Software	Hitachi Dynamic Link Manager (for Windows)	8.7.3-01	Full Package	-

New features and important enhancements

None.

System requirements

Refer to Chapter 3. Creating an HDLM environment of the Hitachi Command Suite Dynamic Link Manager User Guide for Windows®.

Host

For details on supported Hosts, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - HDLM system requirements - OSs supported by HDLM

Supported OSs in a HAM environment are listed as follows:

Supported OS
Windows Server 2012 (x64)
Windows Server 2012 R2 (x64)
Windows Server 2016 (x64)

Supported cluster software in a HAM environment is listed as follows:

OS	Service Pack	Cluster software
Windows Server 2012 (x64)	No service pack	Microsoft Failover Cluster (*1)
Windows Server 2012 R2 (x64)	No service pack	Microsoft Failover Cluster (*1)
Windows Server 2016 (x64)	No service pack	Microsoft Failover Cluster (*1)

*1: A Cluster Shared Volume (CSV) is not supported.

Host Bus Adapter (HBA)

For information on supported HBAs and drivers, refer to Appendix A - Host Bus Adapter (HBA) Support Matrix.

Storage

For details on supported storage systems, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - HDLM system requirements - Storage systems supported by HDLM

Requirements to use a HAM environment are as follows:

- HDLM supports the HAM functionality of the following storage system:
 - Hitachi Universal Storage Platform V/VM
 - Hitachi Virtual Storage Platform
 - HPE XP24000/XP20000
 - HPE P9500
 - HUS VM

The required microprogram versions are listed as follows:

Storage system	Interface	Microprogram version	Remark
Universal Storage Platform V/VM	FC I/F	60-06-10-XX/XX or later	X: voluntary number
		60-07-11-XX/XX or later (*1)	
Virtual Storage Platform	FC I/F	70-01-42-XX/XX or later	X: voluntary number
		70-03-00-XX/XX or later (*1)	
XP24000/XP20000	FC I/F	60-06-10-XX/XX or later	X: voluntary number
		60-07-11-XX/XX or later (*1)	
P9500	FC I/F	70-01-42-XX/XX or later	X: voluntary number
		70-03-00-XX/XX or later (*1)	
HUS VM	FC I/F	73-03-0X-XX/XX or later	X: voluntary number

*1: When you use the HAM functionality with Microsoft Failover Cluster, use this version.

Operating Systems Requirements

For details on supported operating systems, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - HDLM system requirements - OSs supported by HDLM

Prerequisite Programs

None.

Related Programs

For details on related programs, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - HDLM system requirements - Cluster software supported by HDLM

Supported Oracle RAC version:

OS	Version	DB File
Windows 2012 (x64) noSP	11.2.0.4.0 (*1)	ASM
	12.1.0.2 (*1)	ASM
Windows 2012 (x64) R2 noSP	11.2.0.4.0 (*1)	ASM
	12.1.0.2 (*1)	ASM
Windows 2016 (x64)	12.2.0.1 (*1)	ASM
	18.3.0.0 (*1)	ASM
	19.3.0.0 (*1)	ASM
Windows 2019 (x64)	19.3.0.0 (*1)	ASM

*1: It is recommended that you use external redundancy for ASM disk groups. To use normal or high redundancy, contact the Oracle Corporation.

Note:

- 1) A configuration where Oracle RAC is installed on OCFS to share Oracle is not supported.

Memory and Disk Space Requirements

For details on memory and disk space requirements, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - HDLM system requirements - Memory and disk capacity requirements

HDLM Supported Configurations

For details on the condition that HDLM can manage space requirements, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - HDLM system requirements - Number of LUs and paths that are supported in HDLM

Resolved problems

[8.7.3-01 Modifications]

The following problem has been corrected:

- 1) The following vulnerabilities related to the JRE that comes with HDLM.

CVE-2020-2754, CVE-2020-2755, CVE-2020-2756, CVE-2020-2757, CVE-2020-2773, CVE-2020-2781, CVE-2020-2800, CVE-2020-2803, CVE-2020-2805, CVE-2020-2830

[8.7.3-00 Modifications]

The following problem has been corrected:

- 1) The following vulnerabilities related to the JRE that comes with HDLM.

CVE-2019-13117, CVE-2019-13118, CVE-2019-16168, CVE-2020-2583, CVE-2020-2585, CVE-2020-2590, CVE-2020-2593, CVE-2020-2601, CVE-2020-2604, CVE-2020-2654, CVE-2020-2655, CVE-2020-2659

Known problems

- 1) In VSP 5100, 5100H, 5500, 5500H, VSP E990, VSP G200, G350, G370, G400, G600, G700, G800, G900, G1000, G1500, VSP F350, F370, F400, F600, F700, F800, F900, F1500, VSP N400, N600, N800, VSP, USP V/VM, XP7, XP8, P9500, XP24000/20000, and Hitachi Unified Storage VM, LUN 0 to 2047 can be assigned, but the support range for HDLM is from 0 to 255. Therefore, HDLM cannot recognize LUs of 256 to 2047.
- 2) The Emulex FC Port Driver cannot be used.
- 3) In Windows 2012, Windows 2016 and Windows 2019 environment, the output function of performance information using Windows performance monitor console is not supported.
- 4) HDLM does not support the Microsoft Cluster Service and Microsoft Failover Cluster in an environment where Veritas Storage Foundation 5.1 for Windows is used.
- 5) When executing the DLMgetras (utility for collecting error information), specify an output directory which contains only alphanumeric characters. If it contains characters other than an alphanumeric character, the collected information may be outputted to a wrong directory. And when changing the output directory of DLMgetras utility executed from the Windows Start menu, do not enclose the output directory name in double quotation marks (").

Installation precautions

For details on HDLM installation, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Notes on creating an HDLM environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Installing HDLM

Additional Precautions

- 1) When you remove HDLM 5.8.0 to 5.9.1, use the user account used to install HDLM. If HiCommand Device Manager (HDvM) Agent 5.0.0 to 5.8.0 was installed before HDLM 5.8.0 to 5.9.1 was installed, remove.

Updating installation of HDLM precautions

For details on updating HDLM, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Notes on creating an HDLM environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Installing HDLM

Remove precautions

For details on HDLM remove, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Removing HDLM

Usage precautions

Notes on compatibility between versions of HDLM

For details on compatibility between versions of HDLM, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Appendixes A Functional differences between versions of HDLM

Notes on Environment Settings

For details on usage precautions when setting HDLM environment, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM Environment - HDLM system requirements - Number of LUs and paths that are supported in HDLM
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Notes on creating an HDLM environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Setting up HDLM

Notes on General procedures

For details on usage precautions when using HDLM, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 2. HDLM functions - Performing failovers and failbacks using path switching - Path status transition - Status transitions of a path

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 2. HDLM functions - Monitoring intermittent errors(functionality when automatic fallback is used) - Intermittent error monitoring actions
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 3. Creating an HDLM environment - Removing HDLM - Clearing the persistent reservation
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 4. HDLM operation - Notes on using HDLM
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 4. HDLM operation - HDLM operations using the HDLM GUI - Notes on using the HDLM GUI
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 4. HDLM operation - Using commands for HDLM operations - Notes on using commands
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 4. HDLM operation - Reconfiguring the HDLM operating environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 5. Troubleshooting - Checking error information in messages
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows® Chapter 6. Command reference - view (displays information)
- Hitachi Command Suite Dynamic Link Manager GUI Help Section 3.1 HDLM operations using the HDLM GUI
- Hitachi Command Suite Dynamic Link Manager GUI Help Section 5.2 Path Management window

Additional Usage Precautions

- 1) Version numbers are displayed as follows after this version of HDLM is installed.

Function	Item	Version number
HDLM command (dlnkmgr)	HDLM Version	8.7.3-01
	Service Pack Version	Blank
	HDLM Manager	8.7.3-00
	HDLM Alert Driver	8.7.2-00
	HDLM Driver	8.7.2-00
HDLM GUI	HDLM version	8.7.3-01
Registry(*1)	TechnicalVersion	8.7.3-01

*1:Version numbers are stored in the following registry key.

[Key]

- When using Windows 2012, Windows 2016 or Windows 2019

HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\HITACHI\DynamicLinkManager

Notes on HAM functionality support

- 1) In the case of displaying the LU information, the HAM information is not output by specifying the all parameter-value for the HDLM command. Specify theha and hastat parameter-value instead.
- 2) An online operation is performed on an owner path, a non-owner path's status may change to Offline(E). After performing an online operation on an owner path, use the HDLM command to make sure that the non-owner path's status is Online. If the non-owner path's status is Offline(E), change the status of HAM pairs to PAIR, and then perform an online operation on the Offline(E) path again.
- 3) When you set up a HAM pair to be managed by HDLM, make sure that the host recognizes paths to the MCU (Primary VOL) and RCU (Secondary VOL) after the HAM pair is created.

Execute the dlnkmgr view -lu -item hastat operation. If ha is not displayed in the HaStat column, then the corresponding LU is not recognized as being in a HAM configuration.

If the host recognizes the paths to the MCU and RCU before the HAM pair is created, restart the host after the HAM pair is created.

- 4) If you release a HAM pair to recover the system after a HAM volume failure, do not restart a host that is connected to the MCU and RCU while the HAM pair is released.

If you need to restart the host while the HAM pair is released, disconnect all paths to the MCU and RCU, restart the host, re-create the HAM pair, and then reconnect the paths.

If you restart a host that is connected to the MCU and RCU while the HAM pair is released, the RCU volume will be recognized as a volume other than the MCU volume. If this occurs, restart the host after the HAM pair is re-created. Execute the dlnkmgr view -lu -item hastat operation, and then confirm that ha is displayed in the HaStat column.

- 5) If you release a HAM pair to recover the system after a HAM volume failure, do not disconnect or reconnect paths to the RCU while the HAM pair is released.

If you reconnect paths to the RCU while the HAM pair is released, the RCU volume will be recognized as a volume other than the MCU volume. If this occurs, restart the host after the HAM pair is re-created.

- 6) If all the non-owner paths to RCU fail when the status of the owner paths that are connected to MCU is Online(S), a large amount of the following event is output to the system event log.

Source: mpio

Type: Error

Event ID: 32

Description: HDLM Device-Specific Module failed to return a Path to \Device\MPIODiskN.

(N is a number.)

When the status of owner paths is Online(S), do not disconnect the non-owner paths which are connected to the RCU.

- 7) When you configure a cluster in an HAM environment, all cluster nodes need to be connected to both the MCU and RCU.

If a path error occurs in a cluster node, do not restart the node before the problem is resolved and the paths recover from the error.

Notes on Using the HDLM GUI

- 1) If you manage HDLM by using HGLM, do not set the HDLM operating environment in the Options windows. If you set the operating environment in the Option windows, the load balancing algorithm and the path use times for individual LUs, which were set by using HGLM, will become invalid, and the system value displayed in the Option windows will be applied to the settings for the individual LUs.

Documentation

<https://knowledge.hitachivantara.com/Documents>

Available documents

Document name	Document number	Issue date
Hitachi Command Suite Dynamic Link Manager (for Windows®) User Guide	MK-92DLM129-49	May 2020

Appendix A

Host Bus Adapter (HBA) Support Matrix

Use the iSCSI I/F adapter or Fibre Channel I/F adapters listed as follows. If plural adapters are to be used, all of them must be same type. If it is using mixed types of HBA, that might cause a path switch problem.

- 1) For Hitachi storage system (Windows 2012 with no service Pack)

OS	HBA		Driver
Windows 2012 (x64)	Fibre Channel	Emulex	Bundle
			STOR Miniport 2.72.012.001
			STOR Miniport 2.72.205.004
			STOR Miniport 2.74.009.001
			STOR Miniport 2.74.014.001
			STOR Miniport 2.74.016.001
			STOR Miniport 2.76.003.001
			STOR Miniport 10.0.720.0
			STOR Miniport 10.2.261.4
			STOR Miniport 10.2.370.8
			STOR Miniport 10.4.246.0
			STOR Miniport 10.6.114.0
			STOR Miniport 10.7.110.20
			STOR Miniport 11.0.247.0
STOR Miniport 11.1.145.16			
STOR Miniport 11.2.139.0			
STOR Miniport 11.4.142.11			

		STOR Miniport 11.4.204.8
		STOR Miniport 12.0.193.13
		STOR Miniport 12.0.257.9
		STOR Miniport 12.0.367.0
		STOR Miniport 12.2.207.0
		STOR Miniport 12.2.284.0
		STOR Miniport 12.4.243.4
	QLogic	Bundle
		STOR Miniport 3.2.5.0
		STOR Miniport 9.1.9.205
		STOR Miniport 9.1.10.26
		STOR Miniport 9.1.10.27
		STOR Miniport 9.1.11.20
		STOR Miniport 9.1.11.24
		STOR Miniport 9.1.11.26
		STOR Miniport 9.1.11.28
		STOR Miniport 9.1.12.21
		STOR Miniport 9.1.13.20
		STOR Miniport 9.1.15.20
		STOR Miniport 9.1.15.21
STOR Miniport 9.1.17.21		
STOR Miniport 9.1.17.22		
STOR Miniport 9.1.17.25		
STOR Miniport 9.1.18.20		

			STOR Miniport 9.2.1.20
			STOR Miniport 9.2.2.20
			STOR Miniport 9.2.3.20
			STOR Miniport 9.2.4.21
			STOR Miniport 9.2.4.21
			STOR Miniport 9.2.6.22
			STOR Miniport 9.2.8.20
			STOR Miniport 9.2.9.20
			STOR Miniport 9.2.9.23
		Hitachi Compute Blade	Bundle (*1)
		HPE	STOR Miniport 2.74.009.001
			STOR Miniport 9.1.10.27
			STOR Miniport 9.1.11.20
			STOR Miniport 9.1.11.24
			STOR Miniport 9.1.15.21
			STOR Miniport 9.1.17.21
			STOR Miniport 9.1.17.22
			STOR Miniport 9.1.17.25
			STOR Miniport 9.2.4.21
			STOR Miniport 10.7.110.20
		STOR Miniport 11.1.145.16	
		Brocade	Bundle
			STOR Miniport 3.0.2.21

			STOR Miniport 3.1.0.1
			STOR Miniport 3.2.4.0
			STOR Miniport 3.2.5.0
	iSCSI	Microsoft (*2)	Bundle
		Emulex	STOR Miniport 4.9.160.0
			STOR Miniport 10.0.732.0
			STOR Miniport 10.2.370.9
			STOR Miniport 10.2.421.0
			STOR Miniport 10.4.245.0
			STOR Miniport 10.6.116.0
			STOR Miniport 11.0.271.0
			STOR Miniport 11.1.185.0
			STOR Miniport 11.2.1153.23
			STOR Miniport 11.4.1174.0
	QLogic	STOR Miniport 2.1.6.10	
	Fibre Channel over Ethernet	Emulex	Bundle
			STOR Miniport 2.72.012.001
			STOR Miniport 2.72.205.004
			STOR Miniport 2.74.014.001
			STOR Miniport 2.76.003.001
STOR Miniport 10.0.720.0			
STOR Miniport 10.2.261.4			
STOR Miniport 10.2.370.8			
STOR Miniport 10.4.246.0			

			STOR Miniport 10.6.114.0
			STOR Miniport 10.7.110.20
			STOR Miniport 11.0.247.0
			STOR Miniport 11.1.145.16
			STOR Miniport 11.2.1135.0
			STOR Miniport 11.4.1162.0
		QLogic	STOR Miniport 3.2.5.0
			STOR Miniport 9.1.10.15
			STOR Miniport 9.1.11.16
			STOR Miniport 9.1.12.10
			STOR Miniport 9.1.13.10
		HPE	STOR Miniport 2.74.014.001
			STOR Miniport 2.76.003.001
			STOR Miniport 7.13.4.0
			STOR Miniport 7.14.0.0 or later
			STOR Miniport 10.2.261.4
			STOR Miniport 10.4.246.0
			STOR Miniport 10.7.110.20
			STOR Miniport 11.1.145.16
		Brocade	STOR Miniport 3.2.4.0
			STOR Miniport 3.2.5.0
		Cisco	STOR Miniport 2.3.0.12
			STOR Miniport 2.4.0.11
			STOR Miniport 2.4.0.19

2) For Hitachi storage system (Windows 2012 R2 with no service Pack)

OS	HBA		Driver
Windows 2012 R2 (x64)	Fibre Channel	Emulex	Bundle
			STOR Miniport 2.76.002.001
			STOR Miniport 2.76.003.001
			STOR Miniport 10.0.720.0
			STOR Miniport 10.2.261.4
			STOR Miniport 10.2.370.8
			STOR Miniport 10.4.246.0
			STOR Miniport 10.6.114.0
			STOR Miniport 10.7.110.20
			STOR Miniport 11.0.247.0
			STOR Miniport 11.1.145.16
			STOR Miniport 11.2.139.0
			STOR Miniport 11.4.142.11
			STOR Miniport 11.4.204.8
			STOR Miniport 12.0.193.13
			STOR Miniport 12.0.257.9
			STOR Miniport 12.0.318.0
STOR Miniport 12.0.367.0			
STOR Miniport 12.2.207.0			
STOR Miniport 12.2.284.0			
STOR Miniport 12.4.243.4			

			Bundle
			STOR Miniport 3.2.5.0
			STOR Miniport 9.1.11.3
			STOR Miniport 9.1.11.24
			STOR Miniport 9.1.11.28
			STOR Miniport 9.1.12.21
			STOR Miniport 9.1.13.20
			STOR Miniport 9.1.15.20
			STOR Miniport 9.1.15.21
			STOR Miniport 9.1.17.21
			STOR Miniport 9.1.17.22
			STOR Miniport 9.1.17.25
		QLogic	STOR Miniport 9.1.18.20
			STOR Miniport 9.2.1.20
			STOR Miniport 9.2.2.20
			STOR Miniport 9.2.3.20
			STOR Miniport 9.2.4.21
			STOR Miniport 9.2.5.20
			STOR Miniport 9.2.5.21
			STOR Miniport 9.2.6.20
			STOR Miniport 9.2.6.22
			STOR Miniport 9.2.8.20
			STOR Miniport 9.2.9.20
			STOR Miniport 9.2.9.22

			STOR Miniport 9.2.9.23
		Hitachi Compute Blade	Bundle (*1)
			STOR Miniport 4.4.8.2280
		HPE	STOR Miniport 9.1.11.24
			STOR Miniport 9.1.11.28
			STOR Miniport 9.1.12.22
			STOR Miniport 9.1.14.22
			STOR Miniport 9.1.15.21
			STOR Miniport 9.1.17.22
			STOR Miniport 9.1.17.25
			STOR Miniport 9.2.4.21
			STOR Miniport 10.2.370.8
			STOR Miniport 10.4.246.0
			STOR Miniport 10.6.114.0
	STOR Miniport 10.7.110.20		
	STOR Miniport 11.1.145.16		
	Brocade	STOR Miniport 3.2.4.0	
		STOR Miniport 3.2.5.0	
	iSCSI	Microsoft (*2)	Bundle
		Emulex	STOR Miniport 4.9.160.0
STOR Miniport 10.0.732.0			
STOR Miniport 10.2.370.9			
STOR Miniport 10.2.421.0			
STOR Miniport 10.4.245.0			

			STOR Miniport 10.6.116.0	
			STOR Miniport 11.0.271.0	
			STOR Miniport 11.1.185.0	
			STOR Miniport 11.2.1153.23	
			STOR Miniport 11.4.1174.0	
		QLogic	STOR Miniport 2.1.5.38	
			STOR Miniport 2.1.6.10	
		Fibre Channel over Ethernet	Emulex	STOR Miniport 2.76.002.001
				STOR Miniport 2.76.003.001
				STOR Miniport 10.0.720.0
	STOR Miniport 10.2.261.4			
	STOR Miniport 10.2.370.8			
	STOR Miniport 10.4.246.0			
	STOR Miniport 10.6.114.0			
	STOR Miniport 10.7.110.20			
	STOR Miniport 11.0.247.0			
	STOR Miniport 11.1.145.16			
	QLogic	STOR Miniport 11.2.1135.0		
		STOR Miniport 11.4.1162.0		
		STOR Miniport 3.2.5.0		
STOR Miniport 9.1.11.12				
STOR Miniport 9.1.11.16				
			STOR Miniport 9.1.12.10	
			STOR Miniport 9.1.13.10	

		HPE	STOR Miniport 2.76.003.001
			STOR Miniport 7.10.31.0
			STOR Miniport 7.12.41.0
			STOR Miniport 7.13.4.0
			STOR Miniport 7.14.0.0 or later
			STOR Miniport 10.2.261.4
			STOR Miniport 10.4.246.0
			STOR Miniport 10.7.110.20
			STOR Miniport 11.1.145.16
		Brocade	STOR Miniport 3.2.3.1
			STOR Miniport 3.2.4.0
			STOR Miniport 3.2.5.0
		Cisco	STOR Miniport 2.3.0.20
			STOR Miniport 2.4.0.8
			STOR Miniport 2.4.0.9
			STOR Miniport 2.4.0.11
			STOR Miniport 2.4.0.13
			STOR Miniport 2.4.0.19
			STOR Miniport 2.4.0.20

3) For Hitachi storage system (Windows 2016 with no service Pack)

OS	HBA		Driver
Windows 2016 (x64)	Fibre Channel	Emulex	Bundle
			STOR Miniport 11.0.247.8000

			STOR Miniport 11.1.145.16
			STOR Miniport 11.2.139.0
			STOR Miniport 11.4.142.11
			STOR Miniport 11.4.204.8
			STOR Miniport 11.4.334.7
			STOR Miniport 12.0.193.13
			STOR Miniport 12.0.257.9
			STOR Miniport 12.0.318.0
			STOR Miniport 12.0.367.0
			STOR Miniport 12.2.207.0
			STOR Miniport 12.2.284.0
			STOR Miniport 12.4.243.4
		QLogic	Bundle
			STOR Miniport 9.1.15.1
			STOR Miniport 9.1.17.25
			STOR Miniport 9.2.2.20
			STOR Miniport 9.2.3.20
			STOR Miniport 9.2.4.21
			STOR Miniport 9.2.5.20
			STOR Miniport 9.2.5.21
			STOR Miniport 9.2.6.20
			STOR Miniport 9.2.6.22
			STOR Miniport 9.2.8.20
			STOR Miniport 9.2.9.20

			STOR Miniport 9.2.9.22	
			STOR Miniport 9.2.9.23	
		Hitachi Compute Blade	Bundle (*1)	
		HPE	STOR Miniport 9.1.17.25	
			STOR Miniport 9.2.4.21	
			STOR Miniport 11.1.145.16	
		iSCSI	Microsoft (*2)	Bundle
			Emulex	STOR Miniport 11.1.185.0
				STOR Miniport 11.2.1153.23
	STOR Miniport 11.4.1174.0			
	QLogic	STOR Miniport 2.1.6.10		
	Fibre Channel over Ethernet	Emulex	Bundle	
			STOR Miniport 11.0.247.8000	
			STOR Miniport 11.1.145.16	
			STOR Miniport 11.2.1135.0	
			STOR Miniport 11.4.1162.0	
		QLogic	Bundle	
			STOR Miniport 9.1.11.3	
		HPE	STOR Miniport 7.14.0.0 or later	
STOR Miniport 11.1.145.16				
Cisco		STOR Miniport 3.0.0.7		
	STOR Miniport 3.0.0.8			
	STOR Miniport 3.1.0.11			

			STOR Miniport 3.2.0.14
--	--	--	------------------------

4) For Hitachi storage system (Windows 2019 with no service Pack)

OS	HBA		Driver
Windows 2019 (x64)	Fibre Channel	Emulex	Bundle
			STOR Miniport 11.4.225.8009
			STOR Miniport 12.0.298.0
			STOR Miniport 12.0.318.0
			STOR Miniport 12.0.367.0
			STOR Miniport 12.2.207.0
			STOR Miniport 12.4.243.4
	Fibre Channel	QLogic	Bundle
			STOR Miniport 9.1.15.1
			STOR Miniport 9.2.8.21
			STOR Miniport 9.2.9.22
	iSCSI	Microsoft (*2)	Bundle
	Fibre Channel over Ethernet	Emulex	Bundle
			STOR Miniport 11.0.247.8000
QLogic		Bundle	
		STOR Miniport 7.14.15.2	

Notes:

*1: All drivers applied to Hitachi HBA cards for Hitachi Compute Blade are supported.

*2: Network Interface Card in which Ethernet connection is possible is required.

Copyrights and licenses

© 2020 Hitachi, Ltd. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including copying and recording, or stored in a database or retrieval system for commercial purposes without the express written permission of Hitachi, Ltd., or Hitachi Vantara LLC (collectively "Hitachi"). Licensee may make copies of the Materials provided that any such copy is (i) created as an essential step in utilization of the Software as licensed and is used in no other manner; or (ii) used for archival purposes. Licensee may not make any other copies of the Materials. "Materials" mean text, data, photographs, graphics, audio, video and documents.

Hitachi reserves the right to make changes to this Material at any time without notice and assumes no responsibility for its use. The Materials contain the most current information available at the time of publication.

Some of the features described in the Materials might not be currently available. Refer to the most recent product announcement for information about feature and product availability, or contact Hitachi Vantara LLC at https://support.hitachivantara.com/en_us/contact-us.html.

Notice: Hitachi products and services can be ordered only under the terms and conditions of the applicable Hitachi agreements. The use of Hitachi products is governed by the terms of your agreements with Hitachi Vantara LLC.

By using this software, you agree that you are responsible for:

- 1) Acquiring the relevant consents as may be required under local privacy laws or otherwise from authorized employees and other individuals; and
- 2) Verifying that your data continues to be held, retrieved, deleted, or otherwise processed in accordance with relevant laws.

Notice on Export Controls. The technical data and technology inherent in this Document may be subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Reader agrees to comply strictly with all such regulations and acknowledges that Reader has the responsibility to obtain licenses to export, re-export, or import the Document and any Compliant Products.

Hitachi and Lumada are trademarks or registered trademarks of Hitachi, Ltd., in the United States and other countries.

AIX, AS/400e, DB2, Domino, DS6000, DS8000, Enterprise Storage Server, eServer, FICON, FlashCopy, GDPS, HyperSwap, IBM, Lotus, MVS, OS/390, PowerHA,

PowerPC, RS/6000, S/390, System z9, System z10, Tivoli, z/OS, z9, z10, z13, z14, z/VM, and z/VSE are registered trademarks or trademarks of International Business Machines Corporation.

Active Directory, ActiveX, Bing, Excel, Hyper-V, Internet Explorer, the Internet Explorer logo, Microsoft, the Microsoft Corporate Logo, MS-DOS, Outlook, PowerPoint, SharePoint, Silverlight, SmartScreen, SQL Server, Visual Basic, Visual C++, Visual Studio, Windows, the Windows logo, Windows Azure, Windows PowerShell, Windows Server, the Windows start button, and Windows Vista are registered trademarks or trademarks of Microsoft Corporation. Microsoft product screen shots are reprinted with permission from Microsoft Corporation.

All other trademarks, service marks, and company names in this document or website are properties of their respective owners.

Copyright and license information for third-party and open source software used in Hitachi Vantara products can be found at <https://www.hitachivantara.com/en-us/company/legal.html>.